


Ersatzteilliste
Spare parts list
Liste des pièces de rechange
Lista parti di ricambio
Onderdelenlijst
Lista de repuestos

ISM2-JUNKERS - 7719002997



6720904648.ab.G

	Bestell-Nr.	Bezeichnung	Description	Dénomination	Descrizioni	Benaming	Descripción
1	8 747 208 175 0	Abdeckung IxM2	Covering sheet IxM2	Couvercle IxM2	Coperchio IxM2	Afdichting IxM2	Chapa de protección IxM2
2	8 747 208 177 0	Steckersatz	Set of Plugs	Plots connexion	Morsetto	AANSLUITKLEMMEN IPM	Conjunto de conectores
3	8 747 208 173 0	Steckbrücke (4x) everp	Jumper (4x)	Pont enfichable (4x)	Jumper (4x)	Draadbrug (4x)	Kit de accesorios (4x)
4	7 719 001 833	Vorlauffühler	TEMPERATURE SENSOR	VF sonde départ chauffage	VF Sensore temperatura	VERTREKVOELER	Sonda VF
5	8 714 500 071 0	Temperaturfühler	Temperature sensor	Sonde de temperature	Sensore termometrico	Temperatuurvoeler	Sensor de temperatura
6	8 747 208 172 0	Kollektorfühler 35x6 2500mm 20k	Solar collector sensor 35x6 2500mm 20k	Sonde capteur solaire 35x6 2500mm 20k	Sonda collectore solare 35x6 2500mm 20k	Zonnecollectorsensor 35x6 2500mm 20k	Sonda colector solar 35x6 2500mm 20k
7	7 735 502 304	Temperaturfühler NTC RD 6,0 12K 6000mm	Temperature sensor NTC RD 6,0 12K 6000mm	Kit capteurs NTC RD 6,0 12K 6000 emballé	Sonda di temperatura NTC RD 6,0 12K 6000	Temperature Sensor 6x40,6000mm	Sensor temperatura NTC RD 6,0 12K 6000mm
7	7 747 009 881	SF4 Speichertemperaturfühler	SF4 Cylinder temperature sensor	SONDE BALLON COMPLEMENTAIRE NTC12	SF4 Sensore temperatura	'SF4'Boiler temp. Voeler	SF4 Sensor temp. Acumulador
8	1 904 521 346 0	Sicherung T4A (10x)	Fusing element T4A (10x)	Fusible T4A (10x)	Fusibile T4A (10x)	Buissmeltveiligheid T4A (10x)	Fusible T4A (10x)
9	8 737 707 136	Modul ISM2 neutral	Module ISM2 neutral	Module ISM2 neutre	Modulo ISM2 neutra	Module ISM2 neutral	Módulo ISM2 neutro